

ZWISCHENWÄNDE UND HALTER

Abb.	Art.-Nr.	MENGE	Bezeichnung
------	----------	-------	-------------

Anmerkungen:
[ANTARES 100]

1	0.008.3622.0	2	Dichtung
2	0.007.0835.0/10	1	Luftleitblech
3	0.007.0833.0/10	1	Ring
4	0.007.0937.4/10	1	Kl. Schelle
5	0.008.8175.0	1	Stöpsel
6	0.008.8176.0	1	Stöpsel
7	0.008.3590.3/20	1	Zwischenwand
8	2.0112.005.2	4	Schraube M6x1x16
9	2.1470.002.2	4	Dichtscheibe 6
10	0.299.8361.0	2	Dichtung
11	0.008.8177.0	1	Dichtung
12	2.1470.004.2	2	Dichtscheibe 8
13	2.0112.204.2	2	Schraube M8x1.25x14
14	0.008.3589.2/10	1	Bügel
15	0.445.7363.3	1	Kl. Schutzgehäuse
16	2.1470.002.2	3	Dichtscheibe 6
17	2.0112.004.2	3	Schraube m6x1x14
18	2.0112.305.2	2	Schraube M10x1.5x16
19	2.1470.006.2	2	Dichtscheibe 10
20	0.445.7365.0	2	Dichtung
21	0.445.7364.0	1	Dichtung L = mm 250
22	0.008.3445.2	1	Abschirmung - DX/RH/RE
23	0.008.3450.2	1	Abschirmung sx/lh/li
24	0.008.3481.2	1	-
25	0.445.7354.0/30	1	Stopfen
26	0.007.5474.0	1	Dichtung mm 200
27	0.008.3579.0	1	Abschirmung
28	2.0350.454.3	2	Schraube 4.2x13

